

FIG. 1




FIG. 2A




FIG. 2B





FIG. 3



0047576-4004

FIG. 4

A	400			404	408	412
	PLAY	REVIEW	LISTEN TO			
B	PLAY	REVIEW	LISTEN TO	NEW	MESSAGES	11
C	DELETE	ERASE		SAVED	MESSAGES	12
D	SAVE			MESSAGE		337
E	NEXT	SKIP		MESSAGE		339
F	REPEAT	REPLAY		MESSAGE		#
G	ENVELOPE			MESSAGE		334
H	FORWARD			INFORMATION		335
I	RECORD			MESSAGE		336
J	RECORD			a	REPLY	338
K				a	NEW MESSAGE	2
L				OPTIONS		0
M				MARK IT	URGENT	2
N					CONFIRMATION	3
O				MARK IT	PRIVATE	1
P				SEND	MESSAGE	#
Q	MAIN MENU					33#
R	CANCEL	FINISHED				*
S	POUND					#
T	STAR					*
U	GOODBYE	HANG-UP	EXIT			***
	ANY-4-DIGIT NUMBER- i.e. MAILBOX OR EXT.					4 DIGIT NUMBER

FIG. 4